




HybridLight
BRIGHT THINKING.

PUC 150

150 LUMEN EXPANDABLE LANTERN/
FLASHLIGHT & CHARGER

Read instructions prior to use. Refer to the instructions regarding any questions about the use of your PUC 150.

OPERATING YOUR PUC 150 3 Color LED Lantern



Rechargeable Cell Battery: 2000 mAh Lithium-Ion
Charge Output: 5V/1A

**NO BATTERIES TO
EVER REPLACE!**





PUC 150

150 LUMEN EXPANDABLE LANTERN/
FLASHLIGHT & CHARGER

Read instructions prior to use. Refer to the instructions regarding any questions about the use of your PUC 150.

USING YOUR PUC 150 3 Color LED

Operating Your Light

The On/Off button will operate between different lighting modes.

- 1st click: Low LED light (30 lumens, 40 hours of light)
- 2nd click: High LED light (150 lumens, 8 hours of light)
- Hold the power button while light is on to alternate to the next LED Color. White Mode, Red Mode & Green Mode.
- Note: The light will shine the LED Color that was last used when powering up.
- Red Strobe Mode: To enable Red Strobe, double click the power button.

Charging Your Light

When the light is charging, by either solar or USB-C, the charging indicator will show a red light. The indicator will shine brighter with a stronger charge. Leaving your lantern charging for extended periods of time will not harm the rechargeable cell. There are two ways to charge your light:

1. USB-C port: Lift up the rubber guard. Insert the USB-C cable into the smaller of the two ports, insert other end into any standard USB charger or suitable USB wall outlet. Typically 3 hours of charge time is needed to fully charge the light from a standard wall outlet if flashlight is completely drained. The charging indicator will show green when the light is fully charged.
2. Solar panel charge: Position solar panel into the brightest sunlight (or other lighting) possible, with direct light on as much of the panel as possible. Typically charges full in 10 hours of time depending upon brightness and intensity of light source, if the lantern is completely drained.

How to Charge Your Mobile Device or Tablet

Access the USB port under the Rubber Guard. Insert the larger end of the USB cable into the larger of the two ports. Insert the other end of the cable into compatible mobile device. This product will not charge a device when the lantern battery is lower than 20%. This is to reserve power for emergency operation of the lantern.

PRODUCT WARNINGS

Do not use if broken, bent, cracked or damaged parts are present. Any lantern that appears damaged in any way or operates abnormally must be removed from service. Inspect before each use.

- Do not disassemble the lantern. The LED cannot be replaced.
- Do not operate lantern near fire, flammable liquids or in gaseous or explosive atmospheres.
- Do not permit children to use lantern unsupervised.
- Do not shine directly into eyes.
- Unplug unit before attempting any cleaning or maintenance.

WARRANTY INFORMATION

Our products are warranted against all defects in material and workmanship, excludes abuse, misuse, modification or accidents. Before returning any product, a customer service representative must issue you a Return Merchandise Authorization number. Obtain a Return Merchandise Authorization number by calling customer support at **435-674-4700**. Include the original receipt received with the merchandise and send the package to:

HybridLight LLC
attn: Warranty Dept.
566 N. Dixie Dr.
St. George, Utah 84770